



Olympus⁺

Ceramic Water Filter



PRODUCT OF GREECE
MANUFACTURER:
CENTER PLUS SA

RESIN RENEWAL (REGENERATION) INSTRUCTIONS FOR THE LIMESCALE AND NITRATE CARTRIDGES

The cartridge for removing limescale (blue base cap for the small Olympus and yellow base cap for the GIGA) and the cartridge for removing nitrates (red base cap for the small Olympus and white base cap for the GIGA) require resin regeneration as follows:

STANDARD OLYMPUS FILTER (medium):

For water with a hardness of up to 20-22 German degrees, resin regeneration must be carried out approximately every 350 litres of water.

OLYMPUS GIGA FILTER (GIANT):

The same applies as for the standard (medium) water filter. Resin regeneration must be carried out after approximately 350 litres of water, at a hardness of up to 20-22 German degrees.

FOR THE NITRATE CARTRIDGE:

For nitrates of up to 60 degrees, resin regeneration must be carried out after approximately 150 litres of water. For nitrates above 60 degrees, the regeneration procedure must be carried out after fewer litres of water. The more often the procedure is repeated, the better the nitrate reduction will be in both our models (standard & GIGA).



To regenerate the resin in each cartridge so that it can once again reduce calcium-magnesium salts and nitrates, follow the procedure below:

- 1) Unscrew the cartridge from the unit
- 2) Fill a tall narrow 1-2 litre container with water and add 3 full tablespoons of cooking salt, stirring well to dissolve it before putting the cartridge in.
- 3) Immerse the resin cartridge in the water, making sure it is 100% covered by the salt water.
- 4) After approximately 30 - 45 minutes, take the cartridge out of the brine, rinse the outside with tap water and fit it back onto the unit.
- 5) Turn the tap on fully for approximately 1 minute to rinse the brine from inside the cartridge as well, and the procedure is complete.

CHANGING THE RESIN CARTRIDGE

The resin cartridge has a life of 10-12 months (as does the ceramic cartridge with activated carbon), so it must be changed without fail.

CENTER PLUS SA

- ACHARNES: 87 Karamanli Ave (13679)
- ATHENS: 40 Veranzerou St (10432)

- www.olympusplus.com • www.olympusplus.gr • www.olympusplus.cy
- www.olympusplus.ro • www.olympus-plus.bg • e-mail: info@centerplus.gr